



Stainless Steel Hood Catch Installation Instructions Part #: RT34075

Kit Contents

- 2 – Lower Hood Catches w/ Hardware
- 2 – Upper Hood Catches
- 2 – Bolt Strips w/ Hardware
- 1 – Length of Seal Material



Installation

1. Ensure that all components in kit are accounted for.
2. Open the hood and remove the upper and lower hood catches.
3. Install the provided bolt strips onto the upper hood catches and install onto the hood using the provided hardware.
4. Install the lower hood catches using the provided hardware ensuring that the catch is oriented correctly.
5. Close the hood and ensure that the upper and lower hood catches are aligned. Improper alignment may cause premature wear to the rubber portion of the catch.
6. Once the hood catches are properly aligned trim the seal material to fit and install with the adhesive tape in the same position as the original rubber tabs (see Figure 1).

